1、配置机架感知脚本RackAware.py: 注意python语法换行时要使用4个空格

```
#!/usr/bin/python
#-*-coding:UTF-8 -*-
import sys
rack = {"192.168.137.12":"rack1",
    "192.168.137.10":"rack1",
    "192.168.137.11":"rack2",
    }
if __name__ == "__main__":
    print "/" + rack.get(sys.argv[1],"rack0")
```

脚本原理:如rack的服务器IP会使用对应的机架,不在的会使用rack0

2、在Namenode所在机器的core-site.xml中配置topology.script.file.name

```
<name>net.topology.script.file.name
```

- 3、对RackAware.py脚本赋与执行权限,重启Namenode
- 4、重启过程中,如日志出现类似下面内容代表配置生效 2016-10-10 10:00:00:000 INFO

org.apache.hadoop.net.NetworkTopology:Adding a new node:/rack1/192.168.137.31:50010

5、可通过命令查看: hdfs dfsadmin -printTopology

[hadoop@hadoop-senior logs]\$ hdfs dfsadmin -printTopology Rack: /rack1 192.168.137.31:50010 (hadoop-senior.wanka.com)